System Design

An Engineering Approach to Computer Networking

What is system design?

- A computer network provides computation, storage and transmission resources
- System design is the art and science of putting together these resources into a harmonious whole
- Extract the most from what you have

Goal

- In any system, some resources are more freely available than others
 - high-end PC connected to Internet by a 28.8 modem
 - constrained resource is link bandwidth
 - PC CPU and and memory are unconstrained
- Maximize a set of performance metrics given a set of resource constraints
- Explicitly identifying constraints and metrics helps in designing efficient systems
- Example
 - maximize reliability and MPG for a car that costs less than \$10,000 to manufacture

System design in real life

- Can't always quantify and control all aspects of a system
- Criteria such as scalability, modularity, extensibility, and elegance are important, but unquantifiable
- Rapid technological change can add or remove resource constraints (example?)
 - an ideal design is 'future proof'
- Market conditions may dictate changes to design halfway through the process
- International standards, which themselves change, also impose constraints
- Nevertheless, still possible to identify some principles

Some common resources

Most resources are a combination of

- time
- space
- computation
- money
- labor

Time

- Shows up in many constraints
 - deadline for task completion
 - time to market
 - mean time between failures

Metrics

- response time: mean time to complete a task
- throughput: number of tasks completed per unit time
- degree of parallelism = response time * throughput
 - 20 tasks complete in 10 seconds, and each task takes 3 seconds
 - + => degree of parallelism = 3 * 20/10 = 6

Space

Shows up as

- limit to available memory (kilobytes)
- bandwidth (kilobits)
 - + 1 kilobit/s = 1000 bits/sec, but 1 kilobyte/s = 1024 bits/sec!

Computation

- Amount of processing that can be done in unit time
- Can increase computing power by
 - using more processors
 - waiting for a while!

Money

Constrains

- what components can be used
- what price users are willing to pay for a service
- the number of engineers available to complete a task

Labor

- Human effort required to design and build a system
- Constrains what can be done, and how fast

Social constraints

- Standards
 - force design to conform to requirements that may or may not make sense
 - underspecified standard can faulty and non-interoperable implementations
- Market requirements
 - products may need to be backwards compatible
 - may need to use a particular operating system
 - example
 - GUI-centric design

Scaling

- A design constraint, rather than a resource constraint
- Can use any centralized elements in the design
 - forces the use of complicated distributed algorithms
- Hard to measure
 - but necessary for success

Common design techniques

Key concept: *bottleneck*

- the most constrained element in a system
- System performance improves by removing bottleneck
 - but creates new bottlenecks
- In a balanced system, all resources are simultaneously bottlenecked
 - this is optimal
 - but nearly impossible to achieve
 - in practice, bottlenecks move from one part of the system to another
 - example: Ford Model T

Top level goal

- Use unconstrained resources to alleviate bottleneck
- How to do this?
- Several standard techniques allow us to trade off one resource for another

Multiplexing

- Another word for sharing
- Trades time and space for money
- Users see an increased response time, and take up space when waiting, but the system costs less

economies of scale

Multiplexing (contd.)

- Examples
 - multiplexed links
 - shared memory
- Another way to look at a shared resource
 - unshared virtual resource
- Server controls access to the shared resource
 - uses a *schedule* to resolve contention
 - · choice of scheduling critical in proving quality of service guarantees



- Suppose resource has capacity C
- Shared by N identical tasks
- Each task requires capacity c
- If Nc <= C, then the resource is underloaded</p>
- If at most 10% of tasks active, then C >= Nc/10 is enough
 - · we have used statistical knowledge of users to reduce system cost
 - this is statistical multiplexing gain

Statistical multiplexing (contd.)


- Two types: spatial and temporal
- Spatial
 - · we expect only a fraction of tasks to be simultaneously active
- Temporal
 - we expect a task to be active only part of the time
 - + e.g silence periods during a voice call

Example of statistical multiplexing gain

- Consider a 100 room hotel
- How many external phone lines does it need?
 - each line costs money to install and rent
 - tradeoff
- What if a voice call is active only 40% of the time?
 - can get both spatial and temporal statistical multiplexing gain
 - but only in a packet-switched network (why?)
- Remember
 - to get SMG, we need good statistics!
 - if statistics are incorrect or change over time, we're in trouble
 - example: road system

Pipelining

- Suppose you wanted to complete a task in less time
- Could you use more processors to do so?
- Yes, if you can break up the task into independent subtasks
 - such as downloading images into a browser
 - optimal if all subtasks take the same time
- What if subtasks are dependent?
 - for instance, a subtask may not begin execution before another ends
 - such as in cooking
- Then, having more processors doesn't always help (example?)



Pipelining (contd.) What is the best decomposition? If sum of times taken by all stages = R Slowest stage takes time S Throughput = 1/S Response time = R Degree of parallelism = R/S Maximize parallelism when R/S = N, so that S = R/N => equal stages *balanced pipeline*

Batching

- Group tasks together to amortize overhead
- Only works when overhead for N tasks < N time overhead for one task (i.e. nonlinear)
- Also, time taken to accumulate a batch shouldn't be too long
- We're trading off reduced overhead for a longer worst case response time and increased throughput

Exploiting locality

- If the system accessed some data at a given time, it is likely that it will access the same or 'nearby' data 'soon'
- Nearby => spatial
- Soon => temporal
- Both may coexist
- Exploit it if you can
 - caching
 - ${\ensuremath{\,\bullet\,}}$ get the speed of RAM and the capacity of disk

Optimizing the common case

80/20 rule

- 80% of the time is spent in 20% of the code
- Optimize the 20% that counts
 - need to measure first!
 - RISC
- How much does it help?
 - Amdahl's law
 - Execution time after improvement = (execution affected by improvement / amount of improvement) + execution unaffected
 - beyond a point, speeding up the common case doesn't help

Hierarchy

- Recursive decomposition of a system into smaller pieces that depend only on parent for proper execution
- No single point of control
- Highly scaleable
- Leaf-to-leaf communication can be expensive
 - shortcuts help

Binding and indirection

- Abstraction is good
 - allows generality of description
 - e.g. mail aliases
- Binding: translation from an abstraction to an instance
- If translation table is stored in a well known place, we can bind automatically
 - indirection
- Examples
 - mail alias file
 - page table
 - telephone numbers in a cellular system

Virtualization

- A combination of indirection and multiplexing
- Refer to a virtual resource that gets matched to an instance at run time
- Build system as if real resource were available
 - virtual memory
 - virtual modem
 - Santa Claus
- Can cleanly and dynamically reconfigure system

Randomization

- Allows us to break a tie fairly
- A powerful tool
- Examples
 - resolving contention in a broadcast medium
 - choosing multicast timeouts

Soft state

- State: memory in the system that influences future behavior
 for instance, VCI translation table
- State is created in many different ways
 - signaling
 - network management
 - routing
- How to delete it?
- Soft state => delete on a timer
- If you want to keep it, refresh
- Automatically cleans up after a failure
 - but increases bandwidth requirement

Exchanging state explicitly

- Network elements often need to exchange state
- Can do this implicitly or explicitly
- Where possible, use explicit state exchange

Hysteresis

- Suppose system changes state depending on whether a variable is above or below a threshold
- Problem if variable fluctuates near threshold
 - rapid fluctuations in system state
- Use state-dependent threshold, or hysteresis



- Divide actions that happen once per data transfer from actions that happen once per packet
 - Data path and control path
- Can increase throughput by minimizing actions in data path
- Example
 - connection-oriented networks
- On the other hand, keeping control information in data element has its advantages
 - per-packet QoS

Extensibility

- Always a good idea to leave hooks that allow for future growth
- Examples
 - Version field in header
 - Modem negotiation

