


Mobile Health Basics of Signal Processing

Cecilia Mascolo


The sensor data

- Most of the sensor data collected by these devices' sensors is “time series data”.
- A sensor is sampled at specific time intervals; data is discrete but could be seen as relatively “continuous”.
- Time domain representation of signal:




The Continuous Wave

- **Frequency of continuous signal:** how many times a second the wave repeats itself.
 - Measured in **Hertz**: 3Hz means the wave repeats itself three times in one second.
- **Period:** time required to produce a complete waveform.
- (Peak to Peak) **Amplitude:** max height of the wave.



Frequencies variations

- Humans hear 20Hz to 20kHz
- Cats hear 55Hz to 79kHz





Digital Sample of Continuous Signal

- How do we make sure our digital sampling of a continuous signal records “the important” characteristics of the signal?
- A little bit of signal processing recap 😊

Discrete Sampling of a Signal & Aliasing


t_s is the sampling rate can fit curves at two different frequencies (at least)



Nyquist Theorem in Practice

- To avoid aliasing the sampling frequency should be **double** the maximum frequency to be captured in the signal.
 - **Nyquist sampling rate**: rate you need to sample (at least) to have no aliasing
 - Intuition: sample twice per period!
 - Exception (result of compressed sensing): if the signal is sparse you can sample randomly and get away without sampling at twice per period!

Intuition of why the Nyquist rate works...



Frequency 3Hz

Sampling $3 \times 2 = 6 \rightarrow$





unique curve.

Question for you!

- Humans hear at max 22 KHz
- What is the Nyquist rate we should sample at (at least)?


Representation of signal in frequency domain

- Signals can be represented in
 - Time domain
 - Frequency domain



Complex Signals

- Signals are composed of more than one frequency
- Example sum of signals:



Discrete Fourier Transform (DFTs)

- DFTs map the time domain graph into a frequency domain graph
 - They tell us which frequencies are important in the signal
- How? By correlating with various sin/cos waves at different frequencies!

Correlation

$$\sum_{i=0}^N x(i) y(i)$$

Intuition on DFTs

- DFTs **correlate** a wave with $\sin()$ and $\cos()$ waves at different frequencies.

$$X(k) = \sum_{n=0}^{N-1} x(n) e^{-i2\pi kn/N}$$

function

analyzing function

$$e^{-i\theta} = \cos\theta - i\sin\theta$$
$$\theta = 2\pi kn/N$$

DFTs as Correlations of Sinusoids

$$X(k) = \underbrace{\sum_{n=0}^{N-1} x(n) \cos\left(\frac{2\pi kn}{N}\right)}_{\text{CORRELATION WITH COS}} - i \underbrace{\sum_{n=0}^{N-1} x(n) \sin\left(\frac{2\pi kn}{N}\right)}_{\text{CORRELATION WITH SIN}}$$

Workings of DFTs (assume N=4)

- The result for each $X(k)$ is a complex number which represents a vector
- The magnitude of the vector (ie of the two components) is the amplitude in the frequency domain







$$\begin{aligned} X(0) &= x(0) \cos(2\pi \cdot 0 \cdot 0/4) - j x(0) \sin(2\pi \cdot 0 \cdot 0/4) \\ &+ x(1) \cos(2\pi \cdot 1 \cdot 0/4) - j x(1) \sin(2\pi \cdot 1 \cdot 0/4) \\ &+ x(2) \cos(2\pi \cdot 2 \cdot 0/4) - j x(2) \sin(2\pi \cdot 2 \cdot 0/4) \\ &+ x(3) \cos(2\pi \cdot 3 \cdot 0/4) - j x(3) \sin(2\pi \cdot 3 \cdot 0/4) \end{aligned}$$

$$\begin{aligned} X(1) &= x(0) \cos(2\pi \cdot 0 \cdot 1/4) - j x(0) \sin(2\pi \cdot 0 \cdot 1/4) \\ &+ x(1) \cos(2\pi \cdot 1 \cdot 1/4) - j x(1) \sin(2\pi \cdot 1 \cdot 1/4) \\ &+ x(2) \cos(2\pi \cdot 2 \cdot 1/4) - j x(2) \sin(2\pi \cdot 2 \cdot 1/4) \\ &+ x(3) \cos(2\pi \cdot 3 \cdot 1/4) - j x(3) \sin(2\pi \cdot 3 \cdot 1/4) \end{aligned}$$

$$\begin{aligned} X(2) &= x(0) \cos(2\pi \cdot 0 \cdot 2/4) - j x(0) \sin(2\pi \cdot 0 \cdot 2/4) \\ &+ x(1) \cos(2\pi \cdot 1 \cdot 2/4) - j x(1) \sin(2\pi \cdot 1 \cdot 2/4) \\ &+ x(2) \cos(2\pi \cdot 2 \cdot 2/4) - j x(2) \sin(2\pi \cdot 2 \cdot 2/4) \\ &+ x(3) \cos(2\pi \cdot 3 \cdot 2/4) - j x(3) \sin(2\pi \cdot 3 \cdot 2/4) \end{aligned}$$


$$\begin{aligned} X(3) &= x(0) \cos(2\pi \cdot 0 \cdot 3/4) - j x(0) \sin(2\pi \cdot 0 \cdot 3/4) \\ &+ x(1) \cos(2\pi \cdot 1 \cdot 3/4) - j x(1) \sin(2\pi \cdot 1 \cdot 3/4) \\ &+ x(2) \cos(2\pi \cdot 2 \cdot 3/4) - j x(2) \sin(2\pi \cdot 2 \cdot 3/4) \\ &+ x(3) \cos(2\pi \cdot 3 \cdot 3/4) - j x(3) \sin(2\pi \cdot 3 \cdot 3/4) \end{aligned}$$

Sin and Cos Waves at different frequencies





DFT plot

Wave composed of 3 sine waves with frequencies 1 Hz, 4 Hz, and 7 Hz, amplitudes 3, 1 and 0.5
Sampling rate 100Hz



DFT for this wave showing the three frequencies and amplitude.





Fast Fourier Transforms

- Fast way of calculating DFT
 - Intuition: Splitting the computation of even and odd n in the formula recursively and parallelize
 - DFT $\sim O(N^2)$
 - FFT $\sim O(N \log N)$


From time and frequency representations to Spectrograms

- Representation in time and frequency (separately)



Spectrograms

- Representation in frequency and time




From Wikipedia. Word: nineteenth century

How to generate a spectrogram

- For each time window a DFT is calculated and frequency intensity is represented with "colours" which indicate the level.
- The X axis is the time
- The Y axis is the frequency

Filtering of the signal


- Band-pass filter: an operation which ensures that only certain frequencies are kept in the signal
 - Often used to eliminate specific signals: eg heart signals from respiration signals.
- Butterworth Filter:



DWT: Discrete Wavelet Transforms

- DFT or STFT (short-time Fourier Transforms: FTs on a portion of the time segment) fail to capture time and frequency dependencies well.
 - Only known what frequency in an interval.
 - DFTs decompose the signal into sinusoidal basis functions of different frequencies.
- Discrete Wavelet Transforms (DWT) decompose a signal in orthogonal wavelet basis functions. These functions are nonzero over only part of the total signal length.
- DWTs are dilated, translated and scaled versions of a "base" function (wavelet).

DWT: Discrete Wavelet Transforms





Wavelets: intuition

- The various wavelets (with different frequency) are passed through a signal and highlight different regions of the signal, respectively.
- This process is very good for denoising a signal (highlighting the important frequencies).





Denoising with DWT



Bondareva, E., Han, J., Bradlow, W., & Mascolo, C. (2021). Segmentation-free Heart Pathology Detection Using Deep Learning. Graphs from presentation at 2021 43rd Annual International Conference of the IEEE Engineering in Medicine & Biology Society (EMBC).

Windowing

- Used to isolate a small portion of the signal.
- Often a filter is applied to smoothen start and end discontinuities.
- Example of filter function (Hann).



Figures from <https://wiki.aalto.fi/display/ITSP/Windowing> CC

Questions