
TLM Power 3.0 (CBG) User Manual

Version: CBG 3.2 Alpha

DRAFT MANUAL - UPDATED 1Q2015 - Rev f

MY Yasin, C Koch-Hofer, Pascal Vivet, DJ Greaves

March 17, 2015

Contents

1	Introduction	4
1.1	Accounts	4
2	Power Modelling	7
2.1	Customer Accounts	7
2.2	Physical Data Types	8
2.3	Physical unit: Power in Watts	8
2.4	Physical unit: Energy in Joules	9
2.5	Physical unit: Length in Metres	9
2.6	Physical unit: Area in Metres ²	9
2.7	Physical unit: Voltage in Volts	9
2.8	Instrumenting a SystemC module	10
2.9	Technology/Instance configuration file.	10
2.10	Chip/Region Name	11
2.11	Voltage Scaling	12
2.12	Logging Power Consumption: Mode/Phase Approach	13
2.13	Logging Power Consumption: Transaction Energy Approach	14
2.14	Logging Length and Area	15

3	Layout, Distance and Bit Transition Modelling	16
3.1	Place and Route	16
3.2	TLM Wiring Energy Modelling	17
3.3	TLM Wiring Energy Modelling Computation	19
3.4	TLM Wiring Energy Modelling Flags	19
3.5	Transition Density Estimations	20
3.6	TLM Wiring Energy Modelling Example (Blocking Style)	20
3.7	TLM Wiring Energy Modelling Example (Non-Blocking Style)	21
3.8	Non-TLM Wiring Energy Modelling Example	21
4	Physical Reports	21
5	C++ API	21
6	Tracing Facilities	22
6.1	VCD Traces	22
6.2	VCD Trace Table Output	23
6.3	VCD Plot Future Improvements?	24
6.4	Textual Statistics File	24
6.5	SYLK Statistic File	24
7	Options	25
7.1	Net Transitions	25
7.2	DMI Callbacks	26
8	Modelling Example: TAC Simple Basic Platform	26
9	Modelling Example: Energy Logging	27
10	C++ Language API	27
11	Implementation Notes	28
11.1	Compilation Modes	28

12 Messages	29
12.1 Warning Messages	29
12.2 Error Messages	31

1 Introduction

The TLM Power 3.1 library is a framework for logging power consumption for SystemC [3] models with emphasis on TLM (transaction level modelling). It can also help with area and component utilisation modelling. This library defines a set of classes and functions for evaluating the power consumption of the modules of a timed or loosely-timed SystemC platform. A further set of functions can also be used for generating various reports of the simulation of an instrumented platform.

The library works by asking users to re-code their monitored SystemC modules such that they also inherit a base class from our library or else set a SystemC attribute for a monitored module to point to an instance of that base class¹.

The Cambridge version (release 3 onwards) implements energy-based logging for transactions and also adds physical dimensions and place-and-route operations for wire length estimation.

Energy and power are accumulated in **accounts**. A single account can model both energy and power consumption, with energy being the primary representation and power being periodically converted to energy debits. Energy figures are converted back to average power in some forms of report.

Version 3.1 of the library introduces the *customer_id* concept for TLM modelling. Energy quanta can now be recorded against a customer activity as well as the older approach of recording against a hardware component or subsystem. A given quanta can be recorded in both ways giving different views. The new approach gives a CPU core or a even a thread/process on a CPU core an idea of how much of the system's energy it was responsible for using. Clearly some crosstalk will exist in lower parts of a typical system - such as who pays for a cache line eviction which will normally be the evictor with our approach.

1.1 Accounts

The default use of accounts is to use account zero for static power/energy and account one for dynamic power/energy and account two for wiring power, but other accounts can be freely defined. For instance for leakage power and for short circuit energy.

To control account creation, please call the `start_acct` method. If no accounts have been created before the first logging event, the library will create its own default accounts using the following code:

¹This latter approach not tested recently!

```
void pw_accounting_base::start_default_accounts(int n)
{
    if (global_n_accounts_in_use() > 0) return;
    start_acct("STATIC0");
    start_acct("DYNAMIC1");
    if (n > 2) start_acct("WIRING2");
    if (n > 3) start_acct("AUX3");
}
```

A set of accounts is stored in an **observer**. Multiple observers are instantiated for two different reasons:

1. it is desired to accumulate data with various subtotal structures,
2. different reporting formats of data are wanted.

The system provides automatically a global observer that sums all energy and power for a simple output - but even this is subdivided into the static, dynamic and so on accounts.

An observer may be standalone or may include totals for the part of the design hierarchy it is the parent to. This is controlled by a parameter of trace type `sc_pwr::trace_t` passed to the observer when it is attached in the `pw_trace` call. According to the value of this variable, children can be disregarded or else included in the observer's accounts.

```
typedef enum { no_children, sum_children, also_trace_children } trace_t;
```

The third setting of the trace parameter creates multiple observers, these being a standalone (`no_children`) observer for the named module and independent standalone observers for all the children.

```
Signatures:
void pw_trace(pw_trace_file* p_file_pt,
              sc_core::sc_object& p_obj,
              const std::string& p_str,
              trace_t p_do_children=no_children);

void pw_trace(pw_trace_file* p_file_pt,
              sc_core::sc_object& p_obj,
              trace_t p_do_children=no_children);

Example uses:
g_txt_pt = pw_create_txt_trace_file(g_name); // Create an observer
pw_trace(g_txt_pt, the_top, also_trace_children); // Attach it to a module.

pw_trace(g_txt_pt, the_top, "TOP_ALIASNAME", also_trace_children);
```

There is at most one observer of type summing and at most one observer of type standalone for each power module for each trace type. The system itself also creates a top-level, grand total observer that totals the whole design, whether or not such an observer is manually created. The grand total observer is a `sum_children` observer that includes all power modules found from the SystemC top level.

We use the terms *power module* and *component* interchangeably to denote an (SC_MODULE) that inherits `pw_module`.

Currently, the two following kinds of report can be generated:




Figure 1: Example of an Instrumented Platform

1. a time domain plot of the power/energy, a
2. a table of statistics for power and energy which is written at the end of simulation but which can be dumped at intermediate points if desired.

There is also a C++ API so that user code can read accounting information for generating custom reports (§5).

The POWER3 library supports two basic modelling modes:

1. In the **mode/phase** approach the average power consumption of an IP block is set for a period of time (as per the POWER2 [1] library).
2. In the **energy logging** approach quanta of energy are logged into an account.

The two modes can be freely mixed, even within a component. For instance, typically we use the mode/phase approach for static power consumption and the energy logging approach for dynamic and wiring power.

In the mode/phase approach, power consumption is determined by the current state of a component. A component is free to switch state at any time by invoking library primitives (such as `set_static_power`). (There is no protection so a component can change the state of any other component for which it has the C++ object pointer.) The state of the block is a pair that has phase and mode components. There is no difference between phases and modes as far as the library is concerned. Phases are used to refer to short-term functional phases of a component such as wait, read and compute. A mode is typically a particular DPM (Dynamic Power Management) mode such as on, sleep or off). Both are characterized by their standing power while in that mode/phase and the time duration before the next mode/phase is adopted.

To support monitoring the power consumption of any SystemC module, the tracing facilities take advantage of the hierarchy of a SystemC model. Indeed the energy logged by a module with a summing observer is equal to its own plus that of its sub-modules down to the leaves of the module tree. For example, in Figure 1 the energy consumed by the module CLUSTER0 is equal to the total of expended by its CPUs and its ROUTER.

The remainder of this document is organized as follows. Section 2 presents how to model and instrument a TLM platform with power information. Section 6 presents

how to monitor and generate traces from an instrumented TLM platform. Section 3 describes the options relating to physical layout modelling and bit transition counting. Finally, §11 gives some implementation information about this library.

2 Power Modelling

Versions 1 and 2 of the library were based on power mode/phases for components (sleep, standby, active, etc.) whereas version 3 adds support for energy-per-transaction logging.

Mode/phase-based approach: The power consumption of a SystemC module is defined for each operation mode and modules switch between modes and phases throughout the simulation.

Energy-per-transaction approach: SystemC modules log an energy quanta for each transaction they process, based on computations of how much energy is used. For instance, for a bus the energy per transaction may include a component proportional to the burst length field in the generic payload.

The examples folder contains `power3demo` which uses the TLM generic payload and the energy logging approach.

The examples folder contains `t1m_tac` which uses the mode/phase approach. This may no longer compile properly in the pre-beta release of the POWER3 library ?

2.1 Customer Accounts

New in release 3.1 is the `customer_id` that is associated with a 'no_children' style observer. A customer identifier is created by a typical component such as a core, but the observer will record energy credits from all over the system.

A customer identifier is declared as follows

```
sc_pwr::pw_customer_id customer_id;

// constructor:
customer::customer_id(sc_module *, const char *user_name, int idx=-1)
```

It is automatically initialised with a unique internal identifier by its constructor in the library. A coupled observer is also created. It must be associated with a SystemC module for callback reasons but it has no further association with that component. It has a user name and optional index for presentation purposes.

The customer identifier can be passed in to the `record_energy_use` main logging API for energy to be credited under the account.

The customer identifier can be carried around easily in our version of the generic payload provided this is enabled in the macro setting.

```
// Put a customer number in a transaction
PW_TLM_PAYTYPE trans;
trans.set_customer_acct(customer_id);

// At various places, use the following to record energy, not only against
// the local structural observers, but also against the customer noted in
// the payload.
record_energy_use(op_energy, &trans);
```

When customer identifiers are in use and a call to `record_energy_use` is made without a customer identifier being given, the energy is logged to the local structural accounts AND to a special customer account provided by the library called 'anonymous'. (The grand total figure is unaffected - whatever is logged is recorded in this exactly once always.)

2.2 Physical Data Types

As in the SystemC `SC_TIME` class, the TLM Power library implements classes that define units for manipulating power, energy voltage, length and area values (§2.2). It also defines some base classes for defining the power consumption and the running mode of a module during a simulation.

2.3 Physical unit: Power in Watts

Class `PW_POWER` is used to represent electrical power value (internal representation is internally a double and a `PW_POWER_UNIT`). A `pw_power_unit` is an enumerate type representing power physical unit: `pw_fW` for femto-watt, `pw_pW` for pico-watt, ..., `pw_WATT` for watt.

The default power resolution is 1 pico-watt. The power resolution can only be changed by calling the function `pw_set_power_resolution(double)`. This function can only be called during elaboration, cannot be called more than once and cannot be called after constructing an object of type `pw_power` with a non-zero power value. The value of the double argument shall be positive and shall be a power of 10. A report of severity `SC_ERROR` is thrown if these rules are not respected. The value of the power resolution is given by the `pw_get_power_resolution()` function.

The constant `pw_ZERO_POWER` represents a power value of zero. The static method `max()` returns the maximal power value according to the power resolution.

All the traditional arithmetic, relational, equality and assignment operators are supported. A report of severity `SC_WARNING` or `SC_ERROR` is thrown when the result of an arithmetic is not coherent:

When an overflow is detected the resulting value is equal to the maximal power value, when an underflow is detected the resulting value is equal to zero, when a division by zero is detected the resulting value is equal to the maximal power value.

2.4 Physical unit: Energy in Joules

Much like the `pw_power` class, the class `pw_energy` is used to represent electrical energy values and has the same functions. The default energy resolution is 1 pico-joule and the physical unit is also represented by an enumerated type `pw_energy_unit` (i.e. `pw_fJ` for femto-joule, `pw_pJ` for pico-joule, ..., `pw_JOULE` for Joule).

2.5 Physical unit: Length in Metres

Much like the `pw_energy` class, the class `pw_length` is used to represent physical length and has the same functions. The default energy resolution is 1 pico-metre (SHOULD BE micron by default) and the physical unit is also represented by an enumerated type `pw_energy_unit` (i.e. `pw_fm` for femto-metre, `pw_pm` for pico-metre, ..., `pw_METRE` for metre).

2.6 Physical unit: Area in Metres²

Much like the `pw_length` class, the class `pw_area` is used to represent layout area and has the same functions. The default area resolution is the square micron and the physical unit is also represented by an enumerated type `pw_area_unit` (i.e. `pw_squm` for square microns, `pw_sqcm` for square centimeters, `pw_sqmm` for square millimetres and `pw_sqm` for square metres).

2.7 Physical unit: Voltage in Volts

Much like the `pw_energy` class, the class `pw_voltage` is used to represent potential difference values and has the same functions. The default energy resolution is 1 pico-volt (should be VOLTs) and the physical unit is also represented by an enumerated type `pw_energy_unit` (i.e. `pw_fV` for femto-volt, `pw_pV` for pico-volt, ..., `pw_VOLT` for volt).

TODO: THESE UNITS SHOULD ALL BE FULLY DOCUMENTED IN TABLES.

Finally, some arithmetic operators using these various classes plus the `SC_TIME` class are provided for performing multiplication and division with different physical quantity parameters.

2.8 Instrumenting a SystemC module

```
// Approach 1: inheriting the pw_module
class F00:
public sc_module,
public pw_module
{
public:
SC_HAS_PROCESS(F00);
F00(const sc_module_name& p_name, int width):
sc_module(p_name),
pw_module("config.txt")
{

}

// Approach 2 : having a reference to a power base
... details missing
```

Class `pw_module_base` should be listed as a base class of a SystemC module that is instrumented for power monitoring. The SystemC module should also inherit `sc_module` as usual.

The constructor for a module, such as a RAM or CPU, is typically provided with physical size parameters (bit width, number of words, and so on) and it should can use these in setting its placement and power profile. These instantiations parameters can be combined with values read from a technology/instance file and supply voltage settings to determine standing powers and transaction energies.

2.9 Technology/Instance configuration file.

Components that inherit `pw_module` may import a technology/instance configuration file to assist with setting their physical size, allocating power consumption to transactions and naming different power modes and phases.

Normally a defaulting value for the name of the file to be read is given by the SystemC 'kind' of the component. The default name is `power_config-modulekind.txt` where 'modulekind' is the kind identifier.. This approach is suitable where all of the per-instance variations are controlled by the constructor of the `SC_MODULE` and nothing needs reading from the configuration file on a per-instance basis. Values read from the file can be modified by the constructor using, for instance, other parameters read from user globals or module parameters, such as the size of a RAM.

When the `pw_module` constructor is called with no arguments, the module should implement the 'kind' method (i.e. module type name) that returns a constant string whose name is used as the basis for the file to be consulted.

The name of the file to read can alternatively be specified as an argument to the constructor and this again may be based on the SystemC `kind()` or on the SystemC instance name `name()`. Generally the latter is not needed since each instance should be identically parameterised in terms of technology constants, even if different in per-instance parameters, such as size.

An XML version of the file may be supported in the future.

The entries in the file have the following purposes:

- Mode Line: Defines a dynamic power mode and phase.
- Voltage Line: Gives the supply voltage for which the powers in the mode line are correct. Variation w.r.t. supply squared is assumed. If this line is omitted a one volt supply is assumed.
- Size Line: Gives the physical dimensions of a module: a width and length pair. Generally there is no difference between width and length and they are mostly just multiplied to give the module area.
- Location Line: Gives the X/Y coordinates of a module if detailed placement is being used (currently unimplemented; the lowest-common parent approach is used instead).

The syntax of a configuration file respects the following pseudo-EBNF grammar.

line	::=	MODELINE VOLTAGELINE SIZELINE # comment
VOLTAGELINE	::=	v voltage
SIZELINE	::=	s length length
MODELINE	::=	m MODE [PHASE] DYNAMIC STATIC
MODE	::=	string
PHASE	::=	string
DYNAMIC	::=	power
STATIC	::=	power
string	::=	[a-zA-Z..]+
voltage	::=	floating-literal VOLTAGEUNIT
length	::=	floating-literal LENGTHUNIT
power	::=	floating-literal POWERUNIT
VOLTAGEUNIT	::=	fV pV nV uV mV V
LENGTHUNIT	::=	nm um mm cm m
POWERUNIT	::=	fW pW nW uW mW W

A limitation of the parser, currently used, is to not support spaces between the floating-literal and the unit token of the power rule.

2.10 Chip/Region Name

Every component is nominally on a given chip which has a textual name. It is sometimes convenient to use this mechanism on a finer grain and hence the name is sometimes a region name rather than a chip name.

A component is sometimes conveniently allocated a chip/region name as an optional parameter to the area setting calls. Otherwise the specific `set_chip_region(std::string &)` method should be called in the current region. Either approach will recursively set the chip/region for the child objects that are unset.

All regions or chips that are supposed to be different must be given different names by the user.

These calls also enable the chip/region of the current component to be given. If no name is given then the name of the instantiating parent is used. At the top level, if no name is give, then the SystemC `name()` is used.

Chip names and other layout details are reported in the file `physical.txt`. The user can change the name of this file by assigning his own string to this global:

```
const char *sc_pwr::phy_report_name = "physical.txt";
```

2.11 Voltage Scaling

Each component has an associated supply voltage. A component can adjust its local supply voltage using either of the following two calls:

```
void set_vcc(const pw_voltage&,          bool update_children=true);  
void set_vcc(double, pw_voltage_unit, bool update_children=true);
```

By default these will update the supply voltage to all child components on the same chip or region. Note that this will not be the complete chip/region if this call is not made at the top-level component of that chip or region.

Energy consumption is typically proportional to supply voltage squared. Performing a floating-point multiplication for every energy logging operation is expensive and so the energy quanta are typically held pre-scaled in the users component model and recomputed only when the supply voltage (or other PVT component) changes.

To facilitate this, in the user's constructor, the device should first set its supply voltage if it wishes, or else use the voltage inherited from its parent. Then it should call a locally-defined function called `recompute_pvt_parameters()` which is a locally-supplied override to a virtual function (defined in `sc_pwr::pw_module.base`). The POWER3 library will call this function whenever there is a supply voltage or other PVT change. The user's implementation of this function should recompute the energy quanta associated with transactions to be logged in subsequent transactions with that supply voltage. For example.

```
void myram::recompute_sram_pvt_parameters() // Call when Vcc is changed etc..  
{  
    sc_time l_latency = sc_time(0.21 + 3.8e-4 *sqrt(float(m_bits)), SC_NS);  
    pw_power l_leakage = pw_power(82.0 * m_bits, PW_nW);  
    m_read_energy_op = pw_energy(5.0 + 1.2e-4 / 8.0 *m_bits, pw_energy_unit::PW_pJ);  
  
    std::cout << name() << " " << m_bits/8 <<  
        " byte SRAM: leakage_power=" << l_leakage.round3sf() << "\n";  
    set_static_power(l_leakage);  
    m_write_energy_op = 2.0 * m_read_energy_op; // rule of thumb!  
    m_llsc_excess_energy_op = m_write_energy_op;
```

When using mode/phase modelling, the values in the underlying table are multiplied by the ratio of the current voltage to their nominal voltage squared before being returned to the user or installed in accounts.

2.12 Logging Power Consumption: Mode/Phase Approach

The mode/phase-based power consumption approach deals separately with static and dynamic power.

The mode/phase-based power consumption is typically used for static power dissipation. It can also be used for dynamic power when per-transaction energy is not being used. But when dynamic power is being modelled on a per-transaction basis, it is appropriate to set the dynamic power of the mode/phase to zero. This can be achieved by simply not calling `set_dynamic_power` in that component.

The mode/phase-based power consumption of a component is normally announced by that component by calling one of the following convenience functions which determine the current standing powers (static and dynamic):

1. the dynamic power consumption is set using `SET_DYNAMIC_POWER(PW_POWER&)`,
2. the static power consumption is set using `SET_STATIC_POWER(PW_POWER&)`,
3. the mode of power consumption is set using `SET_POWER_MODE(String &)`,
4. the phase of the power mode consumption is set using `SET_POWER_PHASE(String &)`,
5. the phase and power mode can both be set at once using `UPDATE_POWER(String &MODE, String &PHASE)`.

Note that the full signature to `SET_STATIC_POWER` is

```
void set_static_power(const pw_power&, int l_acct = PW_ACCT_STATIC_DEFAULT);
```

and the body of `SET_DYNAMIC_POWER` does the same thing as `SET_STATIC_POWER` but with the account number being `PW_ACCT_DYNAMIC_DEFAULT`. Other account numbers may be freely used for other purposes.

The power mode and phase are strings used for associating a power consumption to any computation mode and phase of a module. Some frequently used power modes and phases are pre-defined: `PW_MODE_ON`, `PW_MODE_OFF`, `PW_PHASE_WAIT`,

The example in Figure ?? presents how to associate different power information to the different computation modes and phases of the FOO module.

When the power behavior of a model just needs to know the current mode and phase, it is possible to use the class `PW_MODULE`. This class is an extension of the class `PW_MODULE_BASE`.

As a running example, these different facilities were used for modelling the power consumption of a simple platform based on the TLM TAC router (§8).

As illustrated by the example of Figure 2 the same behavior as the one of Figure reffig:three can be written more shortly using the class `pw_module`. Indeed, the associations defined in the configuration file can be used with the method `UPDATE_POWER` for setting the power information.




Figure 2: Simple TAC Platform.

```

tac_response tac_multiport_router::b_transport(tlm_generic_payload &trans, sc_time &delay)
{
    unsigned int len = trans.get_data_length();

    ... // Main body of the behavioural model

    sc_time activity_time = ...;

    delay += lt_activity_time; // Or use qk_inc to perform this addition

#ifdef TLM_POWER3
    // bit_width has been set in the constructor... etc
    sc_energy energy_cost = pw_energy((double) (5 * len), pw_energy_unit::PW_pJ);
    pw_module_base::update_energy(energy_cost, lt_activity_time);
#endif
}
    
```

Figure 3: Energy-based instrumentation of TLM call (intra-module component).

The power values associated to a power mode can also be accessed through the `GET_DYNAMIC_POWER` and the `GET_STATIC_POWER` methods. For example, these methods can be used with the basic methods of the class `pw_module` for describing the complex part of a power behavior and still using the method `UPDATE_POWER` for the simple part.

2.13 Logging Power Consumption: Transaction Energy Approach

Power consumption associated with a transaction consists of two components:

1. Inter-module power (proportional to wiring length and number of bits in transaction)
2. Intra-module power (associated with internal operation inside the component).

Figure 3 is a simple illustration of the the approach where transactional energy consumption internal to a module is logged for each transaction. For each transaction, the transport method logs both the intra-module energy consumed and the activity time for which is has been busy.

The cost-per-bit is multiplied by the transaction length to model its dynamic energy use. This energy is is passed to `update_energy` as the first argument where it is

```

trans.pw_set_origin(this, PW_TGP_ADDRESS | PW_TGP_ACCT_SRC, &frontside_bus);
initiator_socket->b_transport(trans, delay);
trans.pw_terminus(this);
}

```

Figure 4: Energy-based instrumentation of TLM call (inter-module component).

logged.

The second argument is either `SC_TIME_ZERO` if utilisation logging is not required or appropriate or else the time for which the component has been active since the last call to `update_energy`. Using loosely-timed models the activity time is either the time accumulated in the current component or the time accumulated between call and return from the transport method according to whatever definition of utilisation is required.

The observers, currently, add the energy part to the dynamic energy aggregate and time part to utilization aggregate. Thus, at any instant, (utilization/simulated time) gives the percentage of time that a module has been busy. In the future one could record utilization per quantum to observe busy periods for a module so as to spread its work load over time or over number of modules if needed.

In the `TLM_POWER3` library, the energy is scaled by the standing supply voltage squared unless the optional `noscale=true` parameter is passed to `update_energy`.

Figure 4 illustrates a basic form of the companion approach where transactional energy consumption consumed in wiring is logged. This is the inter-module energy. See § `refsec:tlmwiringenergy` for full details.

2.14 Logging Length and Area

A component can describe its physical size in its constructor using one of the following `TLM_POWER3` calls:

```

//Set actual dimensions of current component
void set_fixed_dimensions(pw_length x, pw_length y, const char *chipname=0);

// Set additional area of current component
void set_excess_area(pw_length x, pw_length y,
                    float max_aspect_ratio=2.5, const char *chipname=0);
void set_excess_area(pw_area a, float max_aspect_ratio=2.5, const char *chipname=0);

```

The former sets the actual dimensions of the current component, leading to a TARDIS warning if this is smaller than the sum of its components.

The `excess_area` calls describe the additional area of the current component beyond that of the sum of its child components. The component is assumed to be flexible in shape from square up to an oblong of maximum aspect ratio specified.

These calls also enable the chip/region of the current component to be given. If no name is given then the name of the instantiating parent is used. At the top level, if no name is give, then the `SystemC name()` is used.

```

class F00:
public sc_module,
public pw_module
{
public:
SC_HAS_PROCESS(F00);
F00(const sc_module_name& p_name, int width):
sc_module(p_name),
pw_module("config.txt")
{
set_excess_area(pw_length(50.0 * width, PW_um),
pw_length(5.0 * width, PW_um)); // or from tech file
}
};

```

Figure 5: Length and area annotations pw_module.

```
pw_excess_area(PR_MICRON(40),PR_MICRON(40), 0.25);
```

Figure 6: Size Annotation.

Figure 5 illustrates the basic approach to logging a component's area.

Although X/Y dimensions are used to log area, TLM_POWER3 assumes that a component can freely change its aspect ratio from 1:1 to 2:1 to obtain a good layout unless ...

3 Layout, Distance and Bit Transition Modelling

Both net-level interconnects and TLM transactions model data moving some distance with associated charge and discharge of the nets.

It is important not to model both the charge and discharge of a given net, otherwise energy costs will be double counted. We adopt the approach of only counting the zero to one transition of a net as energy consuming.

3.1 Place and Route

Every component may compute and register its excess physical size in two dimensions. The excess size is how much more area the component has than the sum of its sub components. A component may also register its absolute size, in which case the sum of its components is ignored, but a warning is issued if it behaves like a TARDIS, having more internal size (on the same chip) than outside size.

Commonly, some models will include components that do not physically exist inside them. For instance, a DRAM controller might instantiate the DRAM chips inside the controller rather than bothering to route the connections up through the top level of the SoC. TLM_POWER3 supports this style of modelling using the concept of chip names. Any component (`sc_module`) can be specified as having a separate chip name. Its area and power are not included in that of its parent component.

Moreover, the inter-chip wiring model is applied to transactions and nets that cross between chips.

Placement (and hence wiring distance) can be determined in two ways:

- **Geometric Placement.** With geometric placement, every component is allocated 2-D co-ordinates inside the perimeter of its parent. Geometric placement is based on heuristic algorithms based on random numbers. It can give unpredictable results and users should interpret results only after making several runs with different random seeds.
- **Rentian Placement.** With Rentian placement, no actual placement co-ordinates are determined and no random number generation is required. Instead, wiring distances are given according to Rent's Rule based on component area. The lowest-common module that contains the two-ends of an interconnect is found by walking up the module hierarchy until a common SC_MODULE is encountered. The wiring distance is then predicted from the area of that module.

Placement. Every component is allocated 2-D co-ordinates inside the perimeter of its parent. Rather than performing an accurate placement based on geometric tessellations each component is assumed to be a square. This is a simplistic approach which is correct in terms of area but not suitable for physical manufacture. A png plot file is created for the placement to help visualisation.

Wiring area. An additional wiring swell is added to the area of each component based on the number of internal connections it has. Internal connections may be sc.signals or TLM sockets or user-defined.

Geometric Wiring distance. Using geometric modelling, the wiring length between two components is computed as the Manhattan distance between their centres.

Rentian Wiring Distance. Using rentian wiring, ...

3.2 TLM Wiring Energy Modelling

Given that a transaction takes place between two components that are part of a layout, the distance information can be combined with the number of transitioning bits in an envisaged, underlying bus implementation, to compute the wiring energy associated with the transaction. However, there are a number of general considerations to including in a wiring energy model for TLM:

1. Although a single transaction (generic) payload may typically be transferred on a round trip basis from originator, through the bus, NoC and server components back to the originator, not all fields will be active in the underlying bus implementation at each hop.
2. Some hops may be off-chip PCB traces with associated pads that have different energy cost per unit length compared with on-chip interconnects. On-chip connections are typically unidirectional but off-chip connections are sometimes bi-directional using tri-state drivers.

3. The wiring energy can be charged to the source or destination component or be separately accounted.
4. The cost of bit-transition counting is high on most host workstations, so detailed bit toggle counting should be replaced with estimated average values as an user option.

In a simple example, the originator will complete the address field of the payload and, for writes, also the data and byte-enabled fields. The intermediate components will forward these fields, perhaps with minor changes (e.g. address space manipulations at bus bridges or VM units) to the destination. The destination will reply with a low-cost acknowledgment for a write and with the data for a read.

The PW_TLM_PAYLOAD sub-library is provided with the TLM_POWER3 library as an extra component for estimating wiring energy when using the OSCI TLM2.0 TLM library. It has several modes of operation that are controlled by the preprocessor variable PW_TLM_PAYLOAD.

To use the PW_TLM_PAYLOAD LIBRARY, the sockets provided by TLM2.0 must be defined with an additional type parameter that extends the generic payload and the socket use sites must be augmented with additional library calls, as described below. However, the user might typically define their own CPP macros that integrate the TLM 2.0 socket operations with the PW_TLM_PAYLOAD library calls.

The third generic argument to socket definitions must be provided and defined as PW_TLM_TYPES. The signatures to the transaction methods also need to be defined to use PW_TLM_PAYTYPE instead of the standard generic payload.

These two changes have no effect when PW_TLM_PAYLOAD is set to zero since the macros are then defined as their defaults, but for other values the extended generic payload is used.

```
//Providing the third template argument to a socket:
tlm_utils::simple_initiator_socket<tracedriven_core_bt1m, 64, PW_TLM_TYPES> initiator_socket;

//Using the extended generic payload in the transaction methods:
void b_access(PW_TLM_PAYTYPE &trans, sc_time &delay)
```

The three primitives used for bus energy modelling are pw_set_origin, pw_terminus and pw_log_hop calls. These mark the beginning, intermediate steps and end of a TLM payload trajectory.

```
void pw_set_origin(sc_module *where, uint flags=0, bit_transition_tracker *transition_reference=0);
pw_handle *pw_log_hop(sc_module *where, uint flags=0, bit_transition_tracker *transition_reference=0);
void pw_terminus(sc_module *where);
```

The first argument where is the this pointer for the current component. This is used to track the path through the system.

The second argument is the flags. Most flags are sticky and apply to subsequent hops that do not change that flag. In particular, if the flags argument is zero for the next hop then nothing has changed and the next hop has the same properties as the previous hop.

Name	Description	Notes
PW_TGP_ADDRESS	The address field contains live data.	Sticky. &
PW_TGP_DATA	The data field contains live data.	Sticky. &
PW_TGP_LANES	The byte lanes contain live data.	Sticky. &
PW_TGP_MUXD_AD	The address and data fields contain live data which are sent over a common bus.	Sticky. &
PW_TGP_NOFIELDS	No fields contain live data (apart from command + response)	Sticky. &

Table 1: Active payload field PW_TGP_XXX

Name	Description	Notes
PW_TGP_ONCHIP	The next hop uses the on-chip wiring costs.	Sticky. &
PW_TGP_OFFCHIP	The next hop uses the off-chip wiring costs.	Sticky. &

Table 2: Bus energy model PW_TGP_XXX

The third argument is a bus reference. Every transaction is considered to take place over a bus and a bus is a generic set of wires modelled with a `bit_transition_tracker`. Wires present that are not used consume no energy, so it is not important to customise the instance of a bus to its use (e.g. the bus from CPU to memory has address and write data whereas the return bus has just read data). The bus reference is needed so as to check which physical nets are transitioning with respect to their previous value.

3.3 TLM Wiring Energy Modelling Computation

The formula used for energy consumption is a straightforward product of three numbers:

1. the length of the current hop (in millimetres) (from Rentian or other wiring estimator: §3.1)
2. the number of bits that have transitioned (measured or estimated: §3.5)
3. the energy per millimetre per transition for the wiring style being used (taken from technology file)

3.4 TLM Wiring Energy Modelling Flags

The `flags` field is a bitwise OR of one or more of the PW_TGP_XXX flags. Certain flags are mutually exclusive, with only one from each group being allowed.

Name	Description	Notes
PW_TGP_SRC_ACCT	The energy for the next hop(s) should be debited to the current component.	Sticky.
PW_TGP_DEST_ACCT	The unaccounted wiring energy so far should be passed on to a subsequent component.	Sticky.
PW_TGP_CKP_ACCT	The unaccounted wiring energy so far should consolidated to the current or originating component depending on the pertaining sticky in methods.	Non-sticky.

Table 3: Bus energy accounting methods PW_TGP_XXX

3.5 Transition Density Estimations

Rather than measuring the bit hamming distances on every operation, which is expensive, the library uses a so-called β confidence switcher β . This is a template that fully executes a function some first number of times, N , (1000 or so), but after that the average of these first calls is returned instead. This greatly saves execution time for the function.

Two refinements are applied to this basic approach. 1. To avoid warm-up effects, the average of first N calls is disregarded and the second N worth of calls is used for calls $2N$ onwards. 2. To check for non-stationary behaviour, after $2N$ calls, the underlying function is called once in every N applications and the result compared with the average. If it is out of kilter a warning is printed ... (Ed: please be more precise here!).

3.6 TLM Wiring Energy Modelling Example (Blocking Style)

We will first explain its use with the blocking TLM coding style assuming that the TLM is forwarded through one or more passthrough sockets in the NoC or bus model to an endpoint (e.g. a RAM) and returned the same route.

Here is the basic code for an annotated initiator. Note that different fields in the bus are active depending on whether it is a read or a write transaction.

```
// Example code for a blocking TLM initiator:
if (R) trans.set_read(); else trans.set_write();
trans.pw_set_origin(this, PW_TGP_ADDRESS |
                    PW_TGP_ACCT_SRC |
                    ((R)?PW_TGP_DATA|PW_TGP_LANES),
                    &forward_bus);
initiator_socket->b_transport(trans, delay);
trans.pw_terminus(this);
```

The `forward_bus` should be defined in the initiator class using

```
sc_pwr::tlm_bit_transition_tracker forward_bus;
```

and initialised in the constructor by passing it the `this` pointer of the initiating component.

Two calls to `pw_log_hop` are required in a passthrough component to register the forward and backward operations, but flags and bus arguments are not normally needed (see below):

```
// Example code for a passthrough TLM bus or NoC component:
void b_transport(int id, PW_TLM_PAYLOADTYPE &trans, sc_time &delay)
{
    pw_handle *h = trans.pw_log_hop(this); // First call - on entry to the component
    h->record_energy_use(...)
    ... other code
    // No special decorations are needed around the passthrough operation
    passthrough_init_socket->b_transport(trans, delay);
    ... other code
    //Second call, at return operation (the same handle will be returned and can be ignored).
    trans.pw_log_hop(this);
    h->record_energy_use(...)
}
```

The endpoint is much like a hop, but this hop will generally change the active fields. Also, unless using tri-states on a PCB, a different bus should be provided to model separate read and write data busses in a SoC.

```
// Example code for a blocking TLM end point that is to return a payload
// with different fields active and on a separate read bus.
tlm::tlm_command cmd = trans.get_command();
trans.pw_log_hop(this,
    (cmd==tlm::TLM_READ_COMMAND ? PW_TGP_DATA: PW_TGP_NOFIELDS) | PW_TGP_ACCT_CKPK,
    &read_return_bus);
```

3.7 TLM Wiring Energy Modelling Example (Non-Blocking Style)

This text is missing. TODO.

3.8 Non-TLM Wiring Energy Modelling Example

Energy use in individual net transitions that are not part of a TLM payload or which use non-standard TLM interfaces can be logged as follows.

This text is missing. TODO.

4 Physical Reports

Physical report files may be written by the library, including area and layout.

A generated file, default name `physical.txt`, describes the module hierarchy by voltage scaling domain and gives area at each level.

5 C++ API

Each annotated component (type `sc_module`) has a power module of type `pw_module_base` as a base. The basic form of C++ API is provided through the methods of this base class. This contains static information about component size and varying information such as the current mode/phase power for each account.

At any point we can read off the total energy used so far:

```
const sc_pwr::pw_energy l_global_energy = pw_stat_observer_base::get_global_energy();
```

However, each component has a summing or standalone (or both) observers, which provide cumulative data for that component (and also its children for the summing variant). The observer API should be used for reading energy use.

```
// How to get a handle on an observer for the current SC_MODULE:
sc_pwr::pw_stat_observer_base *it = pw_get_observer(this, sc_pwr::no_children);

// How to get a handle on an observer for the current SC_MODULE and its children:
sc_pwr::pw_stat_observer_base *it = pw_get_observer(this, sc_pwr::sum_children);

// How to get a handle on a global summing observer for the complete system:
sc_pwr::pw_stat_observer_base *it = pw_get_observer(0, sc_pwr::sum_children);

sc_start();

...

// At any point then we can print as follows:

std::cout << "Energy in account " << it->get_global_name(0)
           << " is " << it->get_energy(0) << "\n";
std::cout << "Energy in all accounts " << it->get_energy() << "\n";
```

6 Tracing Facilities

Three different forms of trace report can be generated with the TLM_POWER3 library. These include SyLK, VCD, and TEXT. All three include power and energy consumption, utilisation.

Transaction tracing is now being added ...

The library will automatically add up the power and energy used globally but the top module must be traced using one of the trace methods to see this global total in the associated trace file.

Individual sub-systems may also be traced by selecting other points in the hierarchy to trace and passing the associated component as an argument to the power trace function. Each item traced generates a fresh set of totals that include that item and, in common use, all of its children. So the consumption of a component can be included in more than one trace total of a similar form by tracing it and one or more of its parents or by tracing two or more of its parents.

There are two main forms of output trace file. Firstly, a VCD 6.1 trace file recording the power variations along a simulation. Secondly, a textual file or a SYLK (SYmbolic Link) file gathering different statistics about the power and energy consumptions.

6.1 VCD Traces

A VCD trace file records a time-ordered sequence of instantaneous power values during simulation. Energy plots would be monotonic and not that pretty so are not currently supported.

The VCD trace file can be created and opened by calling function `pw_create_vcd_trace_file`. A trace file may be opened during elaboration or at any time during simulation. Energy observers can be traced by calling function `pw_trace`. A trace file shall be opened before values can be traced to that file and values shall not be traced to a given trace file if one or




Figure 7: TAC Power Consumption Waveform.

more delta cycles have elapsed since opening the file. A VCD trace file shall be closed by calling the close() method of the trace object at the end of the simulation.

There are two styles of VCD plotting for energy events: averaging and decaying. For the decaying form of tracing, new energy log events are upwards impulses that then decay. The VCD tracer accumulates new energy while geometrically writing off the old energy. For the averaging form of tracing, we render energy events as rectangles with area proportional to energy use. Their height is the average value in that interval. The rectangle for an energy quanta could possibly best be centred around its log event, but we draw the rectangle ending at the log event. In both styles, phase/mode changes are rendered as rectangles whose duration corresponds to the interval in that phase/mode.

The decaying plot again represents energy as area. This is computed by scaling the initial height of the energy impulse inversely with the decay rate. The time constant for the decay is set as ... XXX.

Figure 7 shows the waveform diagram of the VCD trace file generating by the simulation of a modified simple TAC platform. This uses phase/mode annotations only. As illustrated by the code of Figure 10, the main() method was modified to create the trace file and indicate the modules to monitor. TODO: Can't we capture them all by default?

The first call to the function pw_trace generates the first waveform of the Figure 7. This waveform shows that the power of the module TOP is equal to the sum of the power consumed by all its sub-components (router, timer, ...). Finally, the second call to the function pw_trace generates the second waveform of the Figure 7 which is equal to the power consumed by a TAC multiport router.

Note, you should put your viewer into analog rendering mode in your waveform viewer for the VCD data generated by this tracer.

6.2 VCD Trace Table Output

The VCD generator accepts an optional second argument - a filename to use for a textual plot file. This can be used for gnuplot rendering of the VCD waveforms or for other purposes. It has columns of numeric data separated by tab characters with the timestamp as the first field. This table can include exactly the same data as in the VCD file but is not in VCD format.

To plot the global total you need to apply trace to the top of each tree of modules with

sum_children mode (most designs only have one tree (i.e. they are not forests of SystemC modules)).

A plot_col argument to the trace method allows alters the layout of the plot file entries for that trace as follows:

```
// Gnuplot expects whitespace-separated columns of data and specific
// columns can be extracted using commands such as
// gnuplot> plot "plot.dat" using 1:2 title 'DRAM', "plot.dat" using 1:3 title 'CPU'
typedef enum { DoNotPlot, PlotEachAccount, PlotCombinedAccounts } plot_control_t;
```

6.3 VCD Plot Future Improvements?

The VCD plot legends contain the word energy but the plot is power.

Perhaps the same plot_control.t should be supported for the VCD output itself... Then all accounts within an observer can be summed and shown as one line on the VCD graph.

6.4 Textual Statistics File

A text file gathering different statistics about power consumption can be created and opened by calling function `pw_create_txt_trace_file`. It may be opened during elaboration or at any time during simulation. The modules to monitor are defined by calling function `pw_trace`. A textual file shall be opened before the power changes of the monitored modules and shall be closed by calling the `close()` method of the trace object at the end of the simulation.

As for the VCD trace file, the code of the `main()` method was modified for generating a textual file and indicating the modules to monitor. The first part of this file (Figure ??) contains the elapsed simulation time used for computing the different power statistics and the three following arrays:

- The first array contains the dynamic and static energy (in Joules) consumed by the monitored modules. The percentage values indicate the dynamic or static energy consumed of a module compared to its global consumption.
- The second array contains the same information as the one before but for power consumption (in Watts).
- The third array gives the power contribution (in percentage) of the monitored modules.

The second part of the generated textual file details the power consumption of each module. For example, Figure ?? illustrates the power information given of the first memory bank. As before, this section is composed of three arrays where the column module is replaced by the power modes (e.g. ...'ON') and phases (e.g. 'IDLE', 'READ' ...) used by this memory during the simulation.

6.5 SYLK Statistic File

As for the textual trace file, the SYLK (Symbolic Link) trace file gathers different statistics about power consumption. The functions for managing this format of trace file is the same as the ones for the textual trace file, except their suffix names `TXT_TRACE_FILE` is replaced by `SLK_TRACE_FILE`. The main advantage of this trace file format is to be supported by most of the spreadsheets.

MODULE NAME	DYNAMIC ENERGY	DYNAMIC POWER	DYNAMIC RATIO	STATIC ENERGY	STATIC POWER	STATIC RATIO
TOP	2,804E-07j	1,974E-01w	100,000%	7,449E-09j	5,242E-03w	100,000%
MEMORY1	8,590E-08j	6,045E-02w	30,631%	1,421E-09j	1,000E-03w	19,076%
MEMORY2	7,105E-08j	5,000E-02w	25,335%	1,421E-09j	1,000E-03w	19,076%
ROUTER	4,381E-08j	3,083E-02w	15,622%	1,421E-09j	1,000E-03w	19,076%
MASTER1	4,109E-08j	2,892E-02w	14,652%	3,440E-10j	2,421E-04w	4,618%
MASTER2	3,432E-08j	2,415E-02w	12,238%	1,421E-09j	1,000E-03w	19,076%
TIMER	4,268E-09j	3,004E-03w	1,522%	1,421E-09j	1,000E-03w	19,076%
TOTAL	2,804E-07j	1,974E-01w	100,000%	7,449E-09j	5,242E-03w	100,000%

MODULE NAME	MODE NAME	PHASE NAME	DYNAMIC ENERGY	DYNAMIC POWER	DYNAMIC RATIO	STATIC ENERGY	STATIC POWER	STATIC RATIO
MEMORY1	ON	IDLE	8,590E-08j	6,045E-02w	30,631%	1,421E-09j	1,000E-03w	19,076%
		READ	6,830E-08j	5,000E-02w	79,511%	1,366E-09j	1,000E-03w	96,129%
		WRITE	4,400E-09j	2,000E-01w	5,122%	2,200E-11j	1,000E-03w	1,548%
MEMORY2	ON	IDLE	7,105E-08j	5,000E-02w	25,335%	1,421E-09j	1,000E-03w	19,076%
ROUTER	ON	IDLE	4,381E-08j	3,083E-02w	15,622%	1,421E-09j	1,000E-03w	19,076%
		ROUTE	1,281E-08j	1,000E-02w	29,240%	1,281E-09j	1,000E-03w	90,148%
MASTER1	ON	COMMUNICATE	3,100E-08j	2,214E-01w	70,760%	1,400E-10j	1,000E-03w	9,852%
		COMPUTE	4,109E-08j	2,892E-02w	14,652%	3,440E-10j	2,421E-04w	4,618%
		INIT	4,109E-08j	1,194E-01w	100,000%	3,440E-10j	1,000E-03w	100,000%
MASTER2	ON	COMMUNICATE	1,430E-09j	1,000E-02w	3,480%	1,430E-10j	1,000E-03w	41,570%
		COMPUTE	3,960E-08j	2,000E-01w	96,374%	1,980E-10j	1,000E-03w	57,558%
		INIT	6,000E-11j	2,000E-02w	0,146%	3,000E-12j	1,000E-03w	0,872%
TIMER	ON	INTERRUPT	3,432E-08j	2,415E-02w	12,238%	1,421E-09j	1,000E-03w	19,076%
		CHECK	3,432E-08j	2,415E-02w	100,000%	1,421E-09j	1,000E-03w	100,000%
		COMMUNICATE	2,240E-10j	4,000E-03w	0,653%	5,600E-11j	1,000E-03w	3,941%
		COMPUTE	4,900E-10j	1,000E-02w	1,428%	4,900E-11j	1,000E-03w	3,448%
		IDLE	3,210E-08j	5,000E-02w	93,534%	6,420E-10j	1,000E-03w	45,179%
		INIT	5,790E-10j	1,000E-03w	1,687%	5,790E-10j	1,000E-03w	40,746%
		INTERRUPT	6,000E-12j	2,000E-03w	0,017%	3,000E-12j	1,000E-03w	0,211%
		WRITE	9,200E-10j	1,000E-02w	2,681%	9,200E-11j	1,000E-03w	6,474%
		IDLE	4,268E-09j	3,004E-03w	1,522%	1,421E-09j	1,000E-03w	19,076%
		INTERRUPT	4,268E-09j	3,004E-03w	100,000%	1,421E-09j	1,000E-03w	100,000%
		WRITE	1,193E-09j	1,000E-03w	27,952%	1,193E-09j	1,000E-03w	83,955%
		WRITE	4,950E-10j	5,000E-03w	11,588%	9,900E-11j	1,000E-03w	6,967%
		WRITE	2,580E-09j	2,000E-02w	60,450%	1,290E-10j	1,000E-03w	9,078%

Figure 8: SYLK Statistics.

As presented in Figure 8, the statistics generated are the same as the one gathered in a textual trace file. The first array gives the power consumption, the energy consumption and the power contribution of each monitored modules. The second array gives details about the power consumption of each module.

7 Options

7.1 Net Transitions

The net-transition monitor may be enabled to compute the number of wires that change value in a transaction. This behaviour typically follows well-known patterns, and so energy usage based on net-transitions is not often required to be modelled. However, this facility helps calibrate and confirm such models.




Figure 9: File Tree for a previous release (lib and sh now do not exist).

```

class F00:
public sc_module,
public pw_module
{
public:
SC_HAS_PROCESS(F00);
F00(const sc_module_name& p_name):
sc_module(p_name),
pw_module("config.txt")
{
SC_THREAD(process);
}

void process(void)
{
update_power (PW_MODE_ON, PW_PHASE_IDLE);
wait(10, SC_NS);

// Perform some computation
update_power(PW_MODE_ON, PW_PHASE_COMPUTE);
wait(20, SC_NS);

update_power(PW_MODE_OFF); // Turn off module
}
};
    
```

Figure 10: mode/phase style annotation example based on pw_module.

7.2 DMI Callbacks

Power consumption is not accurately modelled when DMI is in use. The library has an invalidate hook that can be used to si

8 Modelling Example: TAC Simple Basic Platform

The presented modelling facilities were used to model the power behavior of a simple TAC platform (Figure 2). This platform is composed of a first traffic generator MASTER1 which perform memory accesses to the RAM1. The second traffic generator MASTER2 periodically initializes a TIMER and waits for its interrupt. All these components (except the interrupt signal) communicate via a TAC_MULTIPORT_ROUTER.

All the components of this platform were instrumented with timing and power annotations. For instance, the transport method of the TAC_MULTIPORT_ROUTER was instrumented

```

tac_response tac_multiport_router::transport(...)
{
#ifdef TLM_POWER3
    static unsigned l_nb_transaction = 0;
    ++l_nb_transaction;
    pw_power l_dynamic_pwr = request.get_number() * get_dynamic_power(ON, ROUTE);
    pw_power l_static_pwr = get_static_power(ON, ROUTE);
    set_power_mode(PW_MODE_ON);
    set_power_phase(PW_PHASE_ROUTE);
    set_dynamic_power(get_dynamic_power() + l_dynamic_pwr);
    set_static_power(l_static_pwr);
#endif
    ... existing TAC code ...
#ifdef TLM_POWER
    if(l_nb_transaction == 1) this->update_power(ON, IDLE);
    else set_dynamic_power(get_dynamic_power() - l_dynamic_pwr);
    --l_nb_transaction;
#endif

    ... // Remainder of behavioural model
    output_port.do_transport(router_request, response); // TLM CALL
    ...
}

```

Figure 11: Mode/Phase (TLM Power 2 Style) instrumentation of the TAC Multiport Router.

```

#if PW_TLM_PAYLOAD > 0
    POWER3(l_agent.record_energy_use(std_energy_op));
    POWER3(trans.pw_log_hop(this)); //Second call, after return.
#else
    POWER3(record_energy_use(std_energy_op));
#endif

```

Figure 12: Energy quanta logging in b_transport method for dynamic and wiring energy. (Static power still typically uses phase/mode style.)

for modelling the power cost of routing a transaction . This example also illustrates how to use the methods of the classes `pw_module_base` and `pw_module` for modelling a complex behavior using a configuration file.

The code of this platform is delivered with the library and can be compiled as is (i.e. no external dependency other than SystemC).

9 Modelling Example: Energy Logging

The nominal processor example in the tests folder is an example of the preferred, energy quanta logging coding style. This is new in POWER3.

The code from the bus model (`busmux64.cpp`) illustrates the two possible styles of energy logging depending on the detail needed (Figure 12).

10 C++ Language API

We export a C++ Language API for various uses. In the spEEDO project in Cambridge we are exploring power-aware scheduling. One mechanism we provide is for a processor core to read off system-wide and local energy consumption. On the real board, the processor

reads from physical supply measurements and in the TLM model of the same system the processor reads values captured from the POWER3 library.

The main call to use is to apply `pw_stat_observer_base*pw_get_observer(sc_object *)` on part of the design heirarchy. This returns a handle on that part ...

11 Implementation Notes

The TLM Power library is fully compliant with the IEEE 1666 standard and has no dependencies other than the SystemC library itself. It can be used as a static standalone library or as an ST INFRA development kit. To use it, an application shall include either of the following C++ headers:

1. `t1m_power`: this header adds the names `sc_pwr` to the declarative region in which it is declared. It also adds in this namespace all the components requested for using the TLM Power library.
2. `t1m_power.h`: this header adds all of the names from the namespace `sc_pwr` to the declarative region in which it is declared.

The file tree of the complete distribution is presented in Figure 9. At the top a README and a RELEASNOTE file briefly describe this library and how to use it. The LICENSE file describes the licensing and contractual issues of the TLM_POWER library. The 'src' and the 'include' directories contain the source code of the library. The static library version is located in the 'lib' directory. The simple TAC platform presented at §8 is located in the 'examples' directory. This directory also contains an example of a simple platform composed of a producer and a consumer exchanging messages. This document, an overview presentation, and a 'doxygen' documentation of the source code can be found in the directory 'doc' Finally, the 'test' directory contains a set of non-regression tests.

11.1 Compilation Modes

The library can be compiled in verbose mode. It can also be compiled in debug/developer's mode. This is controlled by setting the relevant flags in the environment or at the top of the Makefile.def if used or else as configure options.

12 Messages

12.1 Warning Messages

Message:	Overflow with <code>pw_power</code> data.
Meaning:	Arithmetic operation with power value has generated an overflow.
Message:	Underflow with <code>pw_power</code> data.
Meaning:	Arithmetic operation with power value has generated an underflow.
Message:	Overflow with <code>pw_power_unit</code> data.
Meaning:	Try to use or to perform some operation with invalid unit of power.
Message:	Overflow with <code>pw_energy</code> data.
Meaning:	Arithmetic operation with energy value has generated an overflow.
Message:	Underflow with <code>pw_energy</code> data
Meaning:	Arithmetic operation with energy value has generated an underflow.
Message:	Overflow with <code>pw_energy_unit</code> data.
Meaning:	Try to use or to perform some operation with invalid unit of energy.
Message:	Redefinition of the power couple (XXX, XXX).
Meaning:	The same couple of power mode and power phase was defined more than one time in the same configuration file.
Message:	Reach end of infinite simulation without calling <code>SC_STOP</code> .
Meaning:	For properly generating the textual trace file, the SystemC function <code>SC_STOP</code> shall be called at the end of the simulation.
Message:	Reach end of infinite simulation with non null power value (XXX).
Meaning:	At the end of infinite simulation the module XXX has non-null power value. For preserving coherency, the power consumption of this module will be calculated until the last power modification of the System.

12.2 Error Messages

Message:	Overflow with <code>pw_power_unit</code> data.
Meaning:	Try to create a power value with an incorrect unit.
Message:	Division by zero not allowed with <code>pw_power</code> .
Meaning:	Try to divide a power value with zero.
Message:	Power resolution can only be set during elaboration phase.
Meaning:	Call the <code>SET_POWER_resolution</code> during the simulation phase.
Message:	Power resolution already fixed.
Meaning:	Call the <code>SET_POWER_resolution</code> function more than one time or after constructing a power object different from zero.
Message:	Power value must be positive.
Meaning:	Try to construct a power object with a negative double parameter.
Message:	Overflow with power resolution value.
Meaning:	The <code>SET_POWER_resolution</code> function was called with an incorrect double parameter (greater than $2^{64}-1$ or fewer than 1.0).
Message:	Failed to initialize input stream.
Meaning:	The initialization of an input stream (<code>POWER_UNIT</code> , <code>power</code> , ...) failed.
Message:	Failed to extract power value from input stream.
Meaning:	The token of an input stream was not representing a power value (syntax error).
Message:	Failed to extract power value from input stream
Meaning:	The token of an input stream was not representing a power unit value (syntax error).
Message:	Overflow with <code>pw_energy_unit</code> data.
Meaning:	Try to create an energy value with an incorrect unit.
Message:	Division by zero not allowed with <code>pw_energy</code> .
Meaning:	Try to divide an energy value with zero.
Message:	Energy resolution can only be set during elaboration phase.
Meaning:	Call the <code>SET_ENERGY_resolution</code> during the simulation phase.
Message:	Energy resolution already fixed.
Meaning:	Call the <code>SET_ENERGY_resolution</code> function more than one time or after constructing an energy object different from zero.
Message:	Energy value must be positive.
Meaning:	Try to construct an energy object with a negative double parameter.
Message:	Overflow with energy resolution value.
Meaning:	The <code>SET_ENERGY_resolution</code> function was called with an incorrect double parameter (greater than $2^{64}-1$ or fewer than 1.0).
Message:	Failed to initialize input stream.
Meaning:	The initialization of an input stream (<code>ENERGY_UNIT</code> , <code>energy</code> , ...) failed.
Message:	Failed to extract energy value from input stream.
Meaning:	The token of an input stream was not representing an energy value (syntax error).
Message:	Failed to extract energy value from input stream
Meaning:	The token of an input stream was not representing an energy unit value (syntax error).
Message:	Division by zero not allowed.
Meaning:	Try to divide an energy value with a zero power or time value.
Message:	Overflow with <code>pw_module_base::ATTRIBUTE_ID</code> data.
Meaning:	Internal error code which should not happen.
Message:	Power module must be an <code>SC_OBJECT</code> .
Meaning:	Try to use the <code>pw_module</code> or the <code>pw_module_base</code> class with an object not inheriting of the class <code>SC_OBJECT</code> .
Message:	Unknown power mode: failed to switch from (XXX, XXX) to (XXX, XXX).
Meaning:	Call the <code>UPDATE_POWER</code> method of the class <code>pw_module</code> with power and/or phase parameter not defined in the configuration file.
Message:	Failed to initialize output stream.
Meaning:	The initialization of an output stream (<code>ENERGY_UNIT</code> , <code>energy</code> , ...) failed.
Message:	Failed to open configuration file XXX (YYY).
Meaning:	Unable to open the configuration file XXX for the reason YYY.
Message:	Internal error code associated to the couple (XXX, XXX).
Meaning:	Internal error code which should not happen.
Message:	Syntax error on power value definition in file XXX at line YYY.

Revision History

Version 1 this library was developed, by Hugo Lebreton, for evaluating the power management mechanisms designed for the Magali Platform [2]. This first version was suffering from the following limitations:

1. The power and energy value are defined by raw value which can lead to un-debuggable errors: for example mixing raw values using different implicit units (e.g. milli-watt and pico-watt) or types (e.g. power and energy).
2. The designer has to define intermediary classes and enumerated types for accessing and setting the power values of a SystemC module.
3. The statistic module does not take into account the mode and phase. For example, it was the responsibility of the user intermediary classes to compute the global energy consumed by a module for different mode and phase.
4. The power consumption of a module does not care about the consumption of its sub-module. It was not possible to automatically generate power information on the module CLUSTER0 from its sub-module.

Version 2.0 of this library was developed by C Koch-Hofer, Pascal Vivet at CEA to overcome these problems.

Version 3.0 (CBG) shifted the focus to energy-based modelling of transactions and added physical distances.

References

[1]H. Lebreton and P. Vivet: Power Modeling in SystemC at Transaction Level, Application to a DVFS Architecture. IVLSI'08: International Symposium on VLSI, Montpellier, FR, 2008, pp. 463-466.

[2]H. Lebreton: ModC)lisation de la consommation C)lectrique en SystemC/TLM et rC)duction de la consommation par le contrC4le de mC)canisme DVFS. DiplC4me de recherche technologique, Institut National Polytechnique de Grenoble (INPG), 2009.

[3]IEEE Std. 1666-2005: IEEE: Standard SystemC Language Reference Manual. NY, USA, 2006, ISBN 0-7381-4871-7. <http://standards.ieee.org/getieee/1666/index.html><http://standards.ieee.org/getieee>

[4]IEC Std 61691-4:2004, IEEE Std 1364-2001: Behavioural languages — Part 4: VerilogB. hardware description language. 2004, pp. 349-374.

[5]File Formats that are supported in Excel. <http://office.microsoft.com/en-us/excel/HP100141031033.aspx>

TODO: mention PlotCombinedAccounts for VCD tracing. mention title mention CSV output ? mention .plt variation on vcd